

Keep With Operator's Manual

## VALVE AND PLUMBING KIT 4211 LOADER CASE IH JX55, JX65, JX75, JX85, AND JX95 TRACKTORS NON-CAB

Valve and plumbing kit can be installed using tools ordinarily available. Valve control handle linkage has been factory preassembled for ease of installation. Shut off engine and engage brakes during installation.

**NOTE:** Apply sealant only to all tapered threads unless coupled with swivel adapters. When using teflon tape, wrap tape clockwise (as viewed from end) and wrap only twice. Keep sealant away from first two threads of tapered end to prevent contamination of hydraulic fluid. Do not use sealant on o-ring or flare adapter threads.

### ATTACHING VALVE TO LOADER MOUNTING BRACKET (Figures 1 & 3)


- 1 Install 90° adapter fitting (9) in power beyond port of valve (1). Install adapter fittings (21), female quick couplers (14) and 1" colored bands (15) to working ports of valve (1).
- 2 Fasten valve mounting plate (22) to valve mounting tube (23) using 3/8 x 2-1/4 cap screw (2) and 3/8 lock nuts (5).
- 3 Fasten valve (1) with power beyond port on the bottom to valve mounting plate (22), using 5/16 x 3/4 cap screws (6) and 5/16 lock washers (7) (Figures 1 & 3).
- 4 Fasten decal mounting angle (4) to valve using 5/16 x 3/4 cap screw (6) and 5/16 lock washer (7). Making sure surface of decal mounting angle is clean and dry, remove backing from decal (19) and apply it to decal mounting plate.
- 5 Thread nut (12) onto handle (3). Attach handle (3) to valve (1). Slip boot (13) over handle and cover handle assembly. Attach ball (8) to handle.
- 6 Attach valve mounting tube (23) to right midmounting bracket using 1/2 x 2-1/2 cap screws (25), 1/2 flat washers (24), plus 1/2 lock nuts (27).
- 7 Place square tube plug (28) into top of tube (23).



**WARNING:** Escaping hydraulic fluid under pressure can penetrate skin causing serious injury.

- DO NOT use your hands to check for leaks. Use a piece of cardboard or paper to search for leaks.
- Stop engine and relieve pressure before connecting or disconnecting lines.
- Tighten all connections before starting engine or pressurizing lines.

If any fluid is injected into skin, obtain medical attention immediately or gangrene may result.



**Figure 1**

### PLUMBING CONTROL VALVE TO TRACTOR HYDRAULICS

1. Locate catch basin under u-shaped hydraulic tube, located in front of right rear trumpet housing under tractor operators platform. The u-shaped tube is attached to two other tubes at manifold. Remove u-shaped tube. Also remove tube cap, located toward inside and center on manifold plate.
2. Slide 88" nylon sleeve (18) over 1/2 x 86" hose (16) and install into pressure port on Prince valve (1). Route along valve mounting tube (23), over tractor platform support and connect to lowest connection point on manifold plate.


## 2-7293

- Slide 78" nylon sleeve (11) over 1/2 x 78" hose (10) and connect to 90° fitting (9) at power beyond port at valve (1). Route along valve mounting tube (23) over tractor platform support and connect to top fitting that u-shaped pipe was connected to.
- Slide 82" nylon sleeve (17) over 1/2 x 80" hose (26) and install into tank port on Prince valve (1). Route along valve mounting tube (23), over tractor platform support and connect to center port which was originally capped. Use plastic straps (20) to secure nylon sleeves to hoses at hose ends and to secure hoses under tractor platform.
- Proceed to mounting kit instructions on mounting loader.

**NOTE:** When cycling loader, operate loader according to operation decal (20) on valve box. If direction of control lever is wrong, or loader will not lower, recheck connections shown.



**WARNING:** Escaping hydraulic fluid under pressure can have sufficient force to penetrate skin causing serious personal injury. If injured by escaping hydraulic fluid, obtain medical treatment immediately.



## PRINCE LVR VALVE SERVICE

Following is an outline procedure for disassembling and reassembling valve.



**WARNING:** The valve has a valve relief setting pre-set at the factory. Tampering with this setting can cause serious injury to operator and damage to tractor or loader. Unauthorized adjustments or service to valve relief will VOID WARRANTY of both loader and tractor. If adjustments or service to valve relief are required during warranty period, an authorized service department must be consulted for authorization.

### VALVE DISASSEMBLY (Figure 5)

**NOTE:** It is advisable to mark or tag all parts so they will be reinstalled in their proper position.

1. Slide boot (6) to top of handle (34). Remove hex head cap screws (36) from rod ends (9 & 10). Remove handle with boot and adapter plate (8). Remove nuts (28) and shim washer (31) from spool stud (7) and rod end assemblies (10). Remove spool stud (7) and rod end assemblies (10) from valve.

**NOTE:** Spool adapters (33) are factory assembled. Removal from spools is not necessary. If replacing a damaged adapter, clean threads with alcohol and Loctite primer and install using Loctite® 262.

2. Remove hex head cap screws (13) and detent end caps (14) from both spools. Remove detent sleeve (12) from regen spool. Remove steel balls (20), poppet (21) and poppet spring (19) from detent retainer (24). Remove retaining flat (15) and detent spacer (16) from regen spool.
3. Secure handle end of regen spool. Using a rod through retainer ball holes, remove detent retainer (24) from regen spool.

**NOTE:** Detent retainers (18 & 24) are installed on spools using Loctite® 222 or equivalent. If spool adapter comes loose instead of detent retainer, pull spool completely out of valve and secure spool using vice grips on land section of spool not machined for valve bore.

4. Remove washer (17), centering spring (26) and stop cup (23) from regen spool.
5. Holding in on float detent sleeve (22), push in on float spool from handle end and remove steel balls (20) from float detent retainer (18). Remove float detent sleeve (22), poppet (21), poppet spring (19), retaining flat (15) and spacer (16) from float spool.

6. Secure handle end of float spool. Using a rod through retainer ball holes, remove detent retainer (18) from float spool.

**NOTE:** Detent retainers (18 & 24) are installed on spools using Loctite® 222 or equivalent. If spool adapter comes loose instead of detent retainer, pull spool completely out of valve and secure spool using vice grips on land section of spool not machined for valve bore.

Remove washer (17), centering spring (26) and stop cup (23) from float spool.

7. Push spools in from handle end until rear spool seals (1) are exposed. Using wire hook and screwdriver remove rear spool seals. Push spools in from the rear until front spool seals (1) are exposed. Using wire hook and screwdriver remove front spool seals.
8. Clean all parts, including valve body, in suitable cleaning solvent. After cleaning parts with solvent, use air pressure to blow any dirt or excess solvent from all parts including inside of valve body.

### VALVE REASSEMBLY

1. Examine all parts for wear and damage and replace if necessary.
2. Lubricate all o-rings and spools with oil to prevent damage when assembling.
3. Lubricate all detent and spring centering parts with a light coat of grease before assembling.
4. Reassemble all parts in reverse order of disassembly.

**NOTE:** Use Loctite® 222 or equivalent when installing detent retainers (18 & 24).

### RELIEF VALVE, LOAD CHECK PLUGS and POWER BEYOND SLEEVE

**NOTE:** Relief valve (3), load check plugs (40) and power beyond sleeve (2) may be removed separately to clean, inspect or replace parts without removing valve spools.


**NOTE:** If repairing or replacing relief valve (3), torque larger hex nut (relief body) to 20-25 ft.lbs.

### REPLACING HANDLE PARTS

If replacing damaged handle parts, clean threads with loctite primer and install using Loctite® 242. Torque parts as shown in Figure 5.

**2-7293****PARTS LIST —VALVE AND PLUMBING KIT**

Item	Part No.	Description	QTY.
1	51034	VALVE, Prince LVR (3000 PSI)	1
2	41838-19	SCREW, Cap, 3/8-16 x 2-1/4	2
3	43517	HANDLE, Standard	1
4	43451	ANGLE, Decal Mounting	1
5	41840-3	NUT, Lock, 3/8-16	2
6	41838-26	SCREW, Cap, 5/16-18 x 3/4	4
7	41837-2	WASHER, Lock, 5/16	4
8	38902	BALL, Handle	1
9	32845-2	FITTING, 90° 3/4-16 x 3/4-16	1
10	51477-1	HOSE, 1/2 X 78 (Power Beyond)	1
11	34853-56	NYLON SLEEVE, 1.25 x 78"	1
12	G271506	NUT, Hex, 7/16-20	1
13	43635	BOOT	1
14	6147-8	COUPLER, Female	4
15	36240-9	SPIRAL BAND, Plastic, Blue, 1"	1
	36240-10	SPIRAL BAND, Plastic, Red, 1"	1
	36240-11	SPIRAL BAND, Plastic, Yellow, 1"	1
	36240-12	SPIRAL BAND, Plastic, Green, 1"	1
16	51476-1	HOSE, 1/2 x 86" (Pressure)	1
17	34853-49	NYLON SLEEVE, 1.25 x 82"	1
18	34853-53	NYLON SLEEVE, 1.25 x 88"	1
19	43453	DECAL, Single Handle Control	1
20	8137-1	STRAP, Adjustable	8
21	39280-8	FITTING, Adapter, 3/4-16 O-Ring x 1/2 NPT	4
22	43450	PLATE, Valve Mounting	1
23	51478	TUBE, Valve Mounting	1
24	42502-10	WASHER, Flat, 1/2	2
25	41838-25	SCREW, Cap, 1/2-13 x 2-1/2	2
26	51476-2	HOSE, 1/2 x 80" (Tank)	1
27	41840-5	NUT, Lock, 1/2-13	2



**FIGURE 3**  
**Plumbing Control Valve**  
**to Loader and**  
**Tractor Hydraulics**


**2-7293****PARTS LIST — REPAIR PARTS**

Item	Part No.	Description	QTY.
1	43633	SEAL KIT	1
2	43636	POWER BEYOND SLEEVE	1
3	51033	RELIEF VALVE (2500 PSI)	1
4	43638	FLOAT KIT (Includes items 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23 and 26)	1
5	43639	REGEN KIT (Includes items 12, 13, 14, 15, 16, 17, 19, 20, 21, 24 and 26)	1
6	43635	BOOT	1
7	51076	STUD, Spool	1
8	51078	ADAPTER PLATE	1
9	38900-4	ROD END	1
10	51075	ROD END, Assembly	2
11	51079	CLEVIS	1
14	44476-3	END CAP (Manufacturers part number(HC-V-AA24) stamped on end cap identifies valve and relief setting)	2
25	44743-5	SCREW, Cap, Socket Head, 1/4-20 x 1/2	2
27	44460	PLUG, Load Check	2
28	41836-2	NUT, Hex, 5/16-18	3
29	44743-3	SCREW, Cap, Socket Head, 1/4-20 x 7/8	2
30	51080	PLATE	1
31	51081	WASHER, Shim, 5/16	1
32	G271506	NUT, Hex, 7/16-20	1
33	51077	END, Spool	2
36	44743-4	SCREW, Cap, Socket Head, 5/16-24 x 3/4"	3


**NOTES:** Individual items not listed in repair parts listings are not available seperately

**FIGURE 4  
PRINCE LVR VALVE**

Spool ends do not need to be removed to service valve. If replacing damaged spool end, clean threads using loctite primer and install using loctite 262.



**Figure 5**  
**VALVE EQUIPPED WITH LOCKOUT FEATURE**



**PARTS LIST - JOYSTICK SUB-ASSY WITH DUAL SPOOL LOCK**

Item	Part No.	Description	Qty.
1	*	CLEVIS, Spool Lock	1
2	*	PLATE, Adapter	1
3	55821	STUD, Spool	1
4	55822	END, Rod	1
5	*	SCREW, Cap	3
6	55823	ASSY, Rod End	2
7	*	NUT, Hex	3
8	*	SCREW, Cap	2
9	*	SCREW, Cap	1
10	*	WASHER, Flat	1
11	55824	KIT, Spool Lock Hardware	1
12	56004	KIT, Bent Handle	1
13	55826	KIT, Boot/Cable Tie	1
14	55917	ADAPTER, Float Spool	1
15	55918	ADAPTER, Regen Spool	1
16	55827	KIT, Sub-Assy, Includes Items 1-11	1

\* **NOTE:** Individual items not listed in repair parts listing are not available separately.  
For valve block service parts, see previous page.



## GENERAL TORQUE SPECIFICATIONS

USE THE FOLLOWING TORQUES WHEN SPECIAL TORQUES ARE NOT GIVEN

### Standard American and Metric Cap Screws

AMERICAN STANDARD CAP SCREWS									METRIC CAP SCREWS										
5					8				8.8					10.9					
Typ. Head Markings					Typ. Head Markings				Typ. Head Markings					Typ. Head Markings					
TORQUE					TORQUE				TORQUE					TORQUE					
Size		FT·LBS		N·m		FT·LBS		N·m		Size		FT·LBS		N·m		FT·LBS		N·m	
Inches	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX	Millimeters	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX		
1/4 - 20	6.25	7.25	8.5	10	8.25	9.5	11	13	M6 x 1.00	6	8	8	11	9	11	12	15		
1/4 - 28	8	9	11	12	10.5	12	14	16	M8 x 1.25	16	20	21.5	27	23	27	31	36.5		
5/16 - 18	14	15	19	20	18.5	20	25	27	M10 x 1.50	29	35	39	47	42	52	57	70		
5/16 - 24	17.5	19	23	26	23	25	31	34	M12 x 1.75	52	62	70	84	75	91	102	123		
3/8 - 16	26	28	35	38	35	37	47.5	50	M14 x 2.00	85	103	115	139	120	146	163	198		
3/8 - 24	31	34	42	46	41	45	55.5	61	M16 x 2.50	130	158	176	214	176	216	238	293		
7/16 - 14	41	45	55.5	61	55	60	74.5	81	M18 x 2.50	172	210	233	284	240	294	325	398		
7/16 - 20	51	55	69	74.5	68	75	92	102	M20 x 2.50	247	301	335	408	343	426	465	577		
1/2 - 13	65	72	88	97.5	86	96	116	130	M22 x 2.50	332	404	450	547	472	576	639	780		
1/2 - 20	76	84	103	114	102	112	138	152	M24 x 3.00	423	517	573	700	599	732	812	992		
9/16 - 12	95	105	129	142	127	140	172	190	M27 x 3.00	637	779	863	1055	898	1098	1217	1488		
9/16 - 18	111	123	150	167	148	164	200	222	M30 x 3.00	872	1066	1181	1444	1224	1496	1658	2027		
5/8 - 11	126	139	171	188	168	185	228	251	<p><b>NOTE:</b> These values apply to fasteners as received from supplier, dry or when lubricated with normal engine oil. They do not apply if special graphite or moly sulphide greases or other extreme lubricants are used.</p>										
5/8 - 18	152	168	206	228	203	224	275	304											
3/4 - 10	238	262	322	355	318	350	431	474											
3/4 - 16	274	305	371	409	365	402	495	544											
7/8 - 9	350	386	474	523	466	515	631	698											
7/8 - 14	407	448	551	607	543	597	736	809											
1 - 8	537	592	728	802	716	790	970	1070											
1 - 14	670	740	908	1003	894	987	1211	1337											

### 37° JIC Fittings

Size	Thread Size	Assembly Torque		Tube Connection F. F. F. T.	Swivel Nut or Hose Connection F. F. F. T.
		in.·lb.	ft.·lb.		
-4	7/16 - 20	140 ± 10	12 ± 1	2	2
-5	1/2 - 20	180 ± 15	15 ± 1	2	2
-6	9/16 - 18	250 ± 15	21 ± 1	1 1/2	1 1/4
-8	3/4 - 16	550 ± 25	45 ± 5	1 1/2	1
-12	1 1/16 - 12	1000 ± 50	85 ± 5	1 1/4	1
-16	1 5/16 - 12	1450 ± 50	120 ± 5	1	1
-20	1 5/8 - 12	2000 ± 100	170 ± 10	1	1
-24	1 7/8 - 12	2400 ± 150	200 ± 15	1	1
-32	2 1/2 - 12	3200 ± 200	270 ± 20	1	1

### O-Ring Face Seal Tube/ Hose Swivel Nut

Metric Tube O.D. (mm)	Dash Size	Thread Size (in.)	Swivel Nut Hex Size (in.)	Swivel Nut Torque	
				N·m	lb <sub>f</sub> /ft
5	-3	--	--	--	--
6	-4	9/16 - 18	11/16	16	12
8	-5	--	--	--	--
10	-6	11/16 - 16	13/16	24	18
12	-8	13/16 - 16	15/16	50	37
16	-10	1 - 14	1-1/8	69	51
20	-12	1-3/16 - 12	1-3/8	102	75
22	-14	1-3/16 - 12	--	102	75
25	-16	1-7/16 - 12	1-5/8	142	105
32	-20	1-11/16 - 12	1-7/8	190	140
38	-24	2 - 12	2-1/4	217	160
50.8	-32	--	--	--	--

### SAE O-Ring Fittings

Size	Swivel Nut or Hose	Assembly Torque		F. F. F. T.
		in.·lb.	ft.·lb.	
2	5/16 - 24	90 ± 5	7.5 ± 0.5	1 ± .25
3	3/8 - 24	170 ± 10	14 ± 1	1 ± .25
4	7/16 - 20	220 ± 15	18 ± 1	1 ± .25
5	1/2 - 20	260 ± 15	22 ± 1	1 ± .25
6	9/16 - 18	320 ± 20	27 ± 2	1.5 ± .25
8	3/4 - 16	570 ± 25	48 ± 2	1.5 ± .25
10	7/8 - 14	1060 ± 50	90 ± 5	1.5 ± .25
12	1 1/16 - 12	1300 ± 50	110 ± 5	1.5 ± .25
14	1 3/16 - 12	1750 ± 75	145 ± 6	1.5 ± .25
16	1 5/16 - 12	1920 ± 125	160 ± 6	1.5 ± .25
20	1 5/8 - 12	2700 ± 150	225 ± 12	1.5 ± .25
24	1 7/8 - 12	3000 ± 150	250 ± 12	1.5 ± .25
32	2 1/2 - 12	3900 ± 200	325 ± 15	1.5 ± .25

# INSTALLATION INSTRUCTIONS